

Kelin ډېر ښه ځایونه کې د ښه ځایونو لپاره کارول کېدای شي. دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي. دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي. دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي. دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي.

دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي. دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي. دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي. دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي. دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي.



دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي. دې ډېر ښه ځایونه د ښه ځایونو لپاره کارول کېدای شي.

- Gray 1#
- Gray 2#
- Gray 3#
- Gray 4#
- Gray 5#
- Gray 6#
- Gray 7#
- Gray 8#
- Gray 9#
- Cement Gray
- Dull Gray
- Silver Gray
- Metal Gray
- Luxury Silver
- Glacier White
- Calaeatta
- Pearl Gold
- Slate Gray
- Terra Brown
- Greyish Green
- Yellow Gray
- Soft Khaki
- Yellowish Brown
- Olive Brown
- Brownness
- Dark Brown
- Reddish Brown
- Rock Bslack







01 Clean the tiles and keep it dry



02 Polish with tile wax except the glazed tile



03 Open & Watch, both sides can extruded meanwhile



04 Screw on the nozzle, put on the grout gun



05 Inclined cut the top of the nozzle in 45°



06 Squeeze out 60-80cm long grout in the forepart



07 Evenly squeeze out the tile agent along the gap



08 Press the grout with professional glue-press tools



09 Don't touch in 4-5 hours and remove excess grout then.



10 Keep the tiles dry in 24 hours

□□ □□ □□ □□



Two Component Caulking Gun



02 Cutter Knife



03 Pointing trowel



04 Brush



05 Forming Stick



06 Pointing Knife



07 Masking Tape



08 Stainless Steel Ball



09 Cleaning Awl

□□ □□



□□□□



Creaming Machine Line



Testing Machine



Batching Production Line



Cooling Filling



Filling Machine Line



Film-coated Machine



Real Material Stock



Stock

□□

